



Download the BEA DECODER app
for a quick overview
of settings




IXIO-ST

SAFETY SENSOR FOR AUTOMATIC SLIDING DOORS

(according to EN 16005 and DIN 18650)

User's Guide for product version 0501 and higher
See product label for serial number

DESCRIPTION



- | | | | |
|----|-----------------------------|----|----------------------------------|
| 1. | LCD | 4. | cover |
| 2. | IR-curtain width adjustment | 5. | main connector |
| 3. | IR-lenses | 6. | main adjustment knob |
| | | 7. | IR-curtain angle adjustment knob |

ACCESSORIES




BA: Bracket accessory




CA: Ceiling accessory



RA: Rain accessory




CDA: Curved door accessory



9 V battery

HOW TO USE THE LCD?

DISPLAY DURING NORMAL FUNCTIONING



Opening impulse

Safety




Negative display = active output



To adjust contrast, push and turn the grey button simultaneously.

During normal function only.

FACTORY VALUE VS. SAVED VALUE



displayed value = factory value



displayed value = saved value

NAVIGATING IN MENUS



Push to enter the LCD-menu



Enter password if necessary

Not during the first minute after power-on of the sensor.



Select your language before entering the first LCD-menu.

During the first 30 seconds after power-on of the sensor or later in the diagnostics menu.



Scroll menu items



Select **Back** to return to previous menu or display.



Select **More** to go to next level:

- basic settings
- advanced settings
- diagnostics

CHANGING A VALUE



Scroll menu up-down




Push to select parameter



current value is displayed



Scroll values up-down



more values are displayed



Push to save new value







new value is displayed

CHANGING A ZIP CODE



See application note on ZIP CODE




Validate the last digit in order to activate the new ZIP code:

- v = valid ZIP code, values will be changed accordingly
- x = invalid ZIP code, no values will be changed
- v/x = valid ZIP code, but from a different product.

Only available values will be changed.



VALUE CHECK WITH REMOTE CONTROL



Pressing a parameter symbol on your remote control, displays the saved value directly on the LCD-screen.

Do not unlock first.

1 MOUNTING & WIRING




TIP!


Wiring is compatible with the IRIS.

* Output status when sensor is operational
 ** For compliance with EN 16005 and DIN 18650, connection to door controller test output is required.


2 INFRARED SAFETY FIELD




Activate the visible* spots to verify the position of the IR-curtain.



If necessary, adjust the IR-curtain angle (from -7° to 4° , default 0°).



* Visibility depends on external conditions. When spots are not visible, use the Spotfinder to locate the curtains.
 ** The distance between the inner curtain of the inside door sensor and the inner curtain of the outside door sensor should always be smaller than 20 cm. The distance to the door leaf depends therefore on the thickness of the door leaf.




Part of the detection field can be masked to reduce it. The arrow position determines the width of the detection field.



Always verify the actual detection field width with a piece of paper and not the Spotfinder, which detects the whole emitted field.

Additional adjustments are possible by LCD or remote control (see p. 5)

Mounting height	Detection width
2.00 m	2.00 m
2.20 m	2.20 m
2.50 m	2.50 m
3.00 m	d max
3.50 m	d max



The size of the detection field varies according to the mounting height and the settings of the sensor. The full door width must be covered.

3 SETTINGS

Choose one of the following presettings or adjust the sensor manually (see p.5):



STANDARD: standard in- and outdoor installations

Presettings
Standard



CRITICAL ENVIRONMENT: critical installations due to surroundings or weather

Presettings
Critical env



SHOPPING STREET: installations in narrow streets with pedestrian traffic

Presettings
Shopping str



4 SETUP



STEP OUT OF THE INFRARED FIELD!



SETUP 1 (QUICK)

reference picture



SETUP 2 (ASSISTED)

test of full door cycle +
reference picture



TEST THE GOOD FUNCTIONING OF THE INSTALLATION BEFORE LEAVING THE PREMISES!

OVERVIEW OF SETTINGS

BASIC



Back
More

PRESETTINGS

standard

critical env.

shopping street

factory values for IR immunity and IR number

increased immunity

increased immunity, 1 curtain

IR: IMMUNITY

low

normal

high

higher

highest

normal

high

↑ < 2.8 m ↓ > 2.8 m
For conformity to EN 16005 or DIN 18650 at a mounting height of 2.8 or more, use values 6 and 7.

IR: FREQUENCY

A

B

Sensors mounted close to each other should have a different frequency.

For conformity to BS 7036 at a mounting height of 2.2 m or more, use values 6 and 7.

More
Back

ADVANCED



Back
More



factory value



excludes conformity of the door system according to EN 16005 / DIN 18650 / BS 7036. IR Immunity on values 4 or 5 is incompatible with IR presence time on value 0

IR: WIDTH



Always additionally adjust the arrow position on the sensor with a screwdriver.

IR: NUMBER

service mode

1

2

service mode = no IR detection during 15 minutes (maintenance). This value excludes conformity of the door system to EN 16005 and DIN 18650.

IR: PRESENCE TIME

motion

15 s

30 s

1 min

2 min

5 min

10 min

20 min

60 min

infinite

min. value for DIN18650: 1 min
min. value for EN16005: 30 s

IR: OUTPUT

NO
NC

NC
NO

NC
NC

NO
NO

NO: normally open
NC: normally closed

REDIRECTION

safety

safety + opening

0 presence detection on safety input
1 presence detection on safety and opening input

SMART DAISY CHAIN*

off

1/2

2/2

1/3

2/3

3/3

1/2: 1st sensor in chain of 2; 2/2: 2nd sensor in chain of 2
1/3: 1st in chain of 3; 2/3: 2nd in chain of 3; 3/3: 3rd in chain of 3

FACTORY RESET

full reset

partial reset

partial: outputs are not reset

More
Back

DIAGNOSTICS



ZIP CODE



all parameter settings in zipped format (see application note on ZIP CODE)

ID

unique ID-number

ERROR LOG

last 10 errors + day indication

IR: SPOTVIEW

view of spot(s) that trigger detection

IR: C1 ENERG

signal amplitude received on curtain 1

IR: C2 ENERG












signal amplitude received on curtain 2

- POWERSUPPLY
- OPERATINGTIME
- RESET LOG
- PASSWORD
- LANGUAGE
- ADMIN

supply voltage at power connector
power duration since first startup
delete all saved errors
LCD and remote control password (0000= no password)
language of LCD-menu
enter code to access admin mode

* Setting in combination with an accessory. For more information, see user's guide of accessory

TROUBLESHOOTING

E1	 ORANGE LED flashes 1 x.	The sensor signals an internal fault.	<ol style="list-style-type: none"> 1 Replace sensor.
E2	 ORANGE LED flashes 2 x.	The power supply is too low or too high.	<ol style="list-style-type: none"> 1 Check power supply (in the diagnostics menu of the LCD). 2 Check wiring.
E3	 ORANGE LED flashes 3 x.	The previous sensor in the daisy chain is faulty	<ol style="list-style-type: none"> 1 Replace previous sensor in the chain
E3		The SDC setting does not match with the real product position	<ol style="list-style-type: none"> 1 Lock the SDC position setting
E4	 ORANGE LED flashes 4 x.	The sensor receives not enough IR-energy.	<ol style="list-style-type: none"> 1 Decrease the angle of the IR-curtains. 2 Increase the IR-immunity filter (values >2.8 m). 3 Deactivate 1 curtain.
E5	 ORANGE LED flashes 5 x.	The sensor receives too much IR-energy.	<ol style="list-style-type: none"> 1 Slightly increase the angle of the IR-curtains.
E5		The sensor is disturbed by external elements.	<ol style="list-style-type: none"> 1 Eliminate the cause of disturbance (lamps, rain cover, door controller housing properly grounded).
E8	 ORANGE LED flashes 8 x.	IR power emitter is faulty.	<ol style="list-style-type: none"> 1 Replace sensor.
E8	 ORANGE LED is on.	The sensor encounters a memory problem.	<ol style="list-style-type: none"> 1 Cut and restore power supply. 2 If orange LED lights up again, replace sensor.
E8	 RED LED flashes quickly after an assisted setup.	The sensor sees the door during the assisted setup.	<ol style="list-style-type: none"> 1 Move the IR-curtains away from the door. 2 Install the sensor as close to the door as possible. If needed, use a bracket accessory. 3 Launch a new assisted setup.
E8	 RED LED lights up sporadically.	The sensor vibrates.	<ol style="list-style-type: none"> 1 Check if the sensor is fastened firmly. 2 Check position of cable and cover.
E8		The sensor sees the door.	<ol style="list-style-type: none"> 1 Launch an assisted setup and adjust the IR angle.
E8		The sensor is disturbed by external conditions.	<ol style="list-style-type: none"> 1 Increase the IR-immunity filter to value 3. 2 Select presetting 2 or 3.
E8	 The LED and the LCD-display are off.		<ol style="list-style-type: none"> 1 Check wiring.
E8	The reaction of the door does not correspond to the LED-signal.		<ol style="list-style-type: none"> 1 Check output configuration setting. 2 Check wiring.
E8	 The LCD or remote control does not react.	The sensor is protected by a password.	<ol style="list-style-type: none"> 1 Enter the right password. If you forgot the code, cut and restore the power supply to access the sensor without entering a password during 1 minute.


LED-SIGNAL




Presence detection




LED flashes



LED flashes
x times



LED flashes
red-green



LED flashes
quickly



LED is off

INSTALLATION



The sensor should be fixed firmly to avoid extreme vibrations.



Do not cover the sensor.



Avoid moving objects and light sources in the detection field.



Avoid highly reflective objects in the infrared field.

MAINTENANCE




It is recommended to clean the optical parts at least once a year or more if required due to environmental conditions.



Do not use aggressive products to clean the optical parts.


SAFETY




The door control unit and the door cover profile must be correctly earthed.



Only trained and qualified personnel may install and setup the sensor.



Always test the good functioning of the installation before leaving the premises.



The warranty is invalid if unauthorized repairs are made or attempted by unauthorized personnel.



- The device cannot be used for purposes other than its intended use. All other uses cannot be guaranteed by the manufacturer of the sensor.
- The manufacturer of the door system is responsible for carrying out a risk assessment and installing the sensor and the door system in compliance with applicable national and international regulations and standards on door safety.
- The manufacturer of the sensor cannot be held responsible for incorrect installations or inappropriate adjustments of the sensor.

TECHNICAL SPECIFICATIONS

Supply voltage:	12 V - 24 V AC +/-10% ; 12 V - 30 V DC +/-10% (to be operated from SELV compatible power supplies only)
Power consumption:	< 2.5 W
Mounting height:	2 m to 3.5 m (according to the applicable laws and regulations)
Temperature range:	-25°C to +55°C; 0-95% relative humidity, non condensing
Degree of protection:	IP54
Noise:	< 70 dB
Expected lifetime:	20 years



Detection mode:	Presence Typical response time: < 200 ms (max. 500 ms)
Technology:	Active infrared with background analysis Spot: 5 cm x 5 cm (typ) Number of spots: max. 24 per curtain Number of curtains: 2
Output:	Solid-state-relay (potential and polarity free) Max. contact current: 100 mA Max. contact voltage: 42 V AC/DC Holdtime: 0.3 to 1 s
Test input:	Sensitivity: Low: < 1 V; High: > 10 V (max. 30 V) Response time on test request: typical: < 5 ms
Conformity:	EN 12978; EN 61000-6-2; EN 61000-6-3; EN ISO 13849-1 PL «C» CAT. 2 (under the condition that the door control system monitors the sensor at least once per door cycle); EN 62061; EN 61496-1 ESPE Type 2; EN 50581 EN 16005 Chapter 4.6.8; DIN 18650-1 Chapter 5.7.4; BS 7036-1 Chapter 8.1; EN 60825-1

Specifications are subject to changes without prior notice.
All values are measured in specific conditions and in a temperature of 25°C.



BEA SA | LIEGE Science Park | ALLÉE DES NOISETIERS 5 - 4031 ANGLEUR (BELGIUM) | T +32 4 361 65 65 | F +32 4 361 28 58 | INFO@BEA.BE | WWW.BEASENSORS.COM



BEA hereby declares that the IXIO-ST is in conformity with European directives 2014/30/EU, 2006/42/EC and 2011/65/EU.
Notified Body for EC-type inspection: 0044 - TÜV NORD CERT GmbH, Langemarckstr. 20, D-45141 Essen
EC-type examination certificate number: 44 205 13089612

Angleur, September 2017 Pierre Gardier, authorized representative and responsible for technical documentation
The complete declaration of conformity is available on our website.



This product should be disposed of separately from unsorted municipal waste