

JOIN OUR  
COMMUNITY!



# IXIO-S01 I

## PRESENCE SENSOR FOR AUTOMATIC INDUSTRIAL DOORS

User's Guide for software version 0600 and higher  
(refer to tracking label on product)


ENGLISH



Download the BEA DECODER app  
for a quick overview of settings



### DESCRIPTION



1. LCD
2. IR-curtain width adjustment
3. IR-lenses

4. cover
5. main connector
6. main adjustment knob
7. IR-curtain angle adjustment knob

### ACCESSORIES




BA: Bracket accessory




CA: Ceiling accessory



RA: Rain accessory




CDA: Curved door accessory



9 V battery

## HOW TO USE THE LCD?

### DISPLAY DURING NORMAL FUNCTIONING



Opening impulse

Presence



Negative display = active output



To adjust contrast, push and turn the grey button simultaneously.

*During normal function only.*

### FACTORY VALUE VS. SAVED VALUE



displayed value = factory value



displayed value = saved value

### NAVIGATING IN MENUS



Push to enter the LCD-menu



Enter password if necessary

*Not during the first minute after power-on of the sensor.*



Select your language before entering the first LCD-menu.

*During the first 30 seconds after power-on of the sensor or later in the diagnostics menu.*



Scroll menu items



Select **Back** to return to previous menu or display.



Select **More** to go to next level:

- basic settings
- advanced settings
- diagnostics

### CHANGING A VALUE



Scroll menu up-down




Push to select parameter



*current value is displayed*



Scroll values up-down



*more values are displayed*



Push to save new value





*new value is displayed*

### CHANGING A ZIP CODE



See application note on ZIP CODE




Validate the last digit in order to activate the new ZIP code:

- v = valid ZIP code, values will be changed accordingly
- x = invalid ZIP code, no values will be changed
- v/x = valid ZIP code, but from a different product.



Only available values will be changed.

### VALUE CHECK WITH REMOTE CONTROL



Pressing a parameter symbol on your remote control, displays the saved value directly on the LCD-screen. Do not unlock first.

## 1 MOUNTING & WIRING




Mount the sensor securely.


\* Depending on OUTPUT CONFIGURATION settings

## 2 INFRARED PRESENCE FIELD


ANGLE



Activate the visible\* spots to verify the position of the IR-curtain.




If necessary, adjust the IR-curtain angle (from  $-7^{\circ}$  to  $4^{\circ}$ , default  $0^{\circ}$ ).




\* Visibility depends on external conditions. When spots are not visible, use the Spotfinder to locate the curtains.

WIDTH



Part of the detection field can be masked to reduce it. The arrow position determines the width of the detection field.



Additional adjustments are possible by LCD or remote control (see p. 5)

Always verify the actual detection field width with a piece of paper and not the Spotfinder, which detects the whole emitted field.

The size of the detection field varies according to the mounting height and the settings of the sensor. The full door width must be covered.

### 3 SETTINGS

Choose one of the following presettings or adjust the sensor manually (see p.5):



**STANDARD:** standard in- and outdoor installations

Presettings  
Standard



**CRITICAL ENVIRONMENT:** critical installations due to surroundings or weather

Presettings  
Critical env.



**SHOPPING STREET:** installations in narrow streets with pedestrian traffic

Presettings  
Shopping str.



### 4 SETUP



STEP OUT OF THE INFRARED FIELD!



#### SETUP 1 (QUICK)

reference picture



#### SETUP 2 (ASSISTED)

test of full door cycle +  
reference picture



TEST THE GOOD FUNCTIONING OF THE INSTALLATION BEFORE LEAVING THE PREMISES!



## TROUBLESHOOTING

E1	 ORANGE LED flashes 1 x.	The sensor signals an internal fault.	<ol style="list-style-type: none"> <li>1 Replace sensor.</li> </ol>
E2	 ORANGE LED flashes 2 x.	The power supply is too low or too high.	<ol style="list-style-type: none"> <li>1 Check power supply (in the diagnostics menu of the LCD).</li> <li>2 Check wiring.</li> </ol>
E4	 ORANGE LED flashes 4 x.	The sensor receives not enough IR-energy.	<ol style="list-style-type: none"> <li>1 Decrease the angle of the IR-curtains.</li> <li>2 Increase the IR-immunity filter (values <math>\geq 2.8</math> m).</li> <li>3 Deactivate 1 curtain.</li> </ol>
E5	 ORANGE LED flashes 5 x.	The sensor receives too much IR-energy.	<ol style="list-style-type: none"> <li>1 Slightly increase the angle of the IR-curtains.</li> <li>2 Decrease the IR-immunity filter (values 1-3 <math>&lt; 2.8</math> m).</li> </ol>
E8	 ORANGE LED flashes 8 x.	IR power emitter is faulty.	<ol style="list-style-type: none"> <li>1 Replace sensor.</li> </ol>
	 ORANGE LED is on.	The sensor encounters a memory problem.	<ol style="list-style-type: none"> <li>1 Cut and restore power supply.</li> <li>2 If orange LED lights up again, replace sensor.</li> </ol>
	 RED LED flashes quickly after an assisted setup.	The sensor sees the door during the assisted setup.	<ol style="list-style-type: none"> <li>1 Move the IR-curtains away from the door.</li> <li>2 Install the sensor as close to the door as possible. If needed, use a bracket accessory.</li> <li>3 Launch a new assisted setup.</li> </ol>
	 RED LED lights up sporadically.	The sensor vibrates.	<ol style="list-style-type: none"> <li>1 Check if the sensor is fastened firmly.</li> <li>2 Check position of cable and cover.</li> </ol>
	 RED LED lights up sporadically.	The sensor sees the door.	<ol style="list-style-type: none"> <li>1 Launch an assisted setup and adjust the IR angle.</li> </ol>
	 RED LED lights up sporadically.	The sensor is disturbed by external conditions.	<ol style="list-style-type: none"> <li>1 Increase the IR-immunity filter to value 3.</li> <li>2 Select presetting 2 or 3.</li> </ol>
	 The LED and the LCD-display are off.		<ol style="list-style-type: none"> <li>1 Check wiring.</li> </ol>
	The reaction of the door does not correspond to the LED-signal.		<ol style="list-style-type: none"> <li>1 Check output configuration setting.</li> <li>2 Check wiring.</li> </ol>
	The LCD or remote control does not react.	The sensor is protected by a password.	<ol style="list-style-type: none"> <li>1 Enter the right password. If you forgot the code, cut and restore the power supply to access the sensor without entering a password during 1 minute.</li> </ol>


## LED-SIGNAL




Presence detection



LED flashes



LED flashes  
x times



LED flashes  
red-green




LED flashes  
quickly



LED is off

## INSTALLATION



The sensor should be fixed firmly to avoid extreme vibrations.



Do not cover the sensor.




Avoid moving objects and light sources in the detection field.




Avoid highly reflective objects in the infrared field.

## MAINTENANCE



It is recommended to clean the optical parts at least once a year or more if required due to environmental conditions.




For complete cleaning, remove both windows by inserting a screwdriver into the notches located between the two windows.



Do not use aggressive products to clean the optical parts.

## SAFETY




The door control unit and the door cover profile must be correctly earthed.



Only trained and qualified personnel may install and setup the sensor.



Always test the good functioning of the installation before leaving the premises.



The warranty is invalid if unauthorized repairs are made or attempted by unauthorized personnel.



- The sensor cannot be used for purposes other than its intended use.
- The manufacturer of the door system incorporating the sensor is responsible for compliance of the system to applicable national and international regulations and safety standards.
- The installer must read, understand and follow the instructions given in this manual. Improper installation can result in improper sensor operation.
- The manufacturer of the sensor cannot be held responsible for injury or damage resulting from incorrect use, installation or inappropriate adjustment of the sensor.

## TECHNICAL SPECIFICATIONS

Supply voltage*:	12 V - 24 V AC +/-10% ; 12 V - 30 V DC +/-10%
Power consumption:	< 2.5 W
Mounting height:	2 m to 4 m
Temperature range:	-25°C to +55°C; 0-95% relative humidity, non condensing
Degree of protection:	IP54 (IEC/EN 60529)
Noise:	< 70 dB



Detection mode:	Presence Typical response time: < 200 ms (max. 500 ms)
-----------------	---

Technology:	Active infrared with background analysis Spot: 5 cm x 5 cm (typ) Number of spots: max. 24 per curtain Number of curtains: 2
-------------	--

Output*:	Solid-state-relay (potential and polarity free) Max. contact current: 100 mA Max. contact voltage: 42 V DC / 30 V AC Holdtime: 0.3 to 1 s
----------	---

\* External electrical sources must be within specified voltages, max 15W and ensure double insulation from primary voltages.

Specifications are subject to changes without prior notice.

All values are measured in specific conditions and with a temperature of 25°C.



BEA SA | UEGE Science Park | Allée des Noisetiers, 5 - 4031 ANGLEUR [BELGIUM] | T +32 4 361 65 65 | F +32 4 361 28 58 | info-eu@beasensors.com | www.beasensors.com



BEA hereby declares that this product is in conformity with the European directives :  
2014/30/EU (EMC) and 2011/65/EU (RoHS).

The complete declaration of conformity is available on our website.



This product should be disposed of separately from unsorted municipal waste